


# Cameo

## Quick start guide

FR GUIDE DE DÉMARRAGE RAPIDE  
DE KURZANLEITUNG  
NL SNELSTARTGIDS  
RU Краткое руководство  
JP クイックスタートガイド  
KO 빠른 시작 가이드  
ZH 快速使用指南

### Start




### Decaf



### Steam



### Option



EN Before using this product, please read the instructions for use carefully. This machine is intended for use only to make coffee and tea with or without milk (option).

All product buttons are Start/Stop. The general STOP button, immediately stops all running products.

FR Veuillez lire attentivement le mode d'emploi avant d'utiliser ce produit. Cette machine est destinée à être utilisée uniquement pour faire du café et du thé avec ou sans lait (en option).

Tous les boutons produit sont Start/Stop. Le bouton général STOP arrête immédiatement tous les produits en cours d'exécution.

DE Bitte lesen Sie vor Gebrauch dieses Produkts die vollständigen Anweisungen sorgfältig durch. Dieses Gerät ist nur für die Zubereitung von Kaffee und Tee mit oder ohne Milch vorgesehen (Option).

Alle Produkttasten sind Start / Stop. Die allgemeine STOP-Taste stoppt sofort alle laufenden Produkte.

NL Lees voor gebruik van dit product de volledige gebruikshandleiding zorgvuldig door. Deze machine is alleen bedoeld om koffie en thee te maken met of zonder melk (optie).

Alle productknoppen zijn Start / Stop. De algemene STOP-knop stopt onmiddellijk alle draaiende producten.

RU Прежде чем приступить к работе, внимательно ознакомьтесь с руководством по эксплуатации. Эта кофе-машина предназначена для приготовления кофе и чая и может иметь опцию приготовления молочных напитков. Все кнопки работают в режиме Старт/Стоп. Кнопка СТОП на дисплее останавливает любой напиток в процессе приготовления.

JP 本製品を使用する前に、使用説明書をよくお読みください。このマシンは、ミルク入りまたはミルク入りのコーヒーと紅茶を作るためのものです(オプション)。製品のボタンはすべてスタート/ストップです。一般的なSTOPボタンは、実行中のすべての製品を直ちに停止します。


KO 이 제품의 안전한 사용을 위해, 본 안내서의 전체를 숙지한 후 사용하시기 바랍니다. 이 기계는 우유 또는 우유가있는 커피와 차를 만들 때만 사용하도록 되어 있습니다 (옵션). 모든 제품 단추는 시작 / 중지입니다. 일반 STOP 버튼은 실행중인 모든 제품을 즉시 중지합니다.

ZH 在使用这个机器前，请先仔细阅读使用说明。本机器只制作咖啡或茶，加不加牛奶（可选）。所有产品的按钮是开始/停止。一般停止按钮能立即停止所有正在运行的产品。



SCAN THE QR CODE  
TO ACCESS MORE INFORMATION

# Cleaning



# Cameo

## Quick start guide

**Day**

24h

1

2

Milk Tank Cleaning

3

4

1 x (25 ml)

5

6

Milk Tank Cleaning

7

8

Grounds Drawer

9

Month

31

1

2

3



### CONSUMABLES



EVERCLEAN

EVERSYS CLEANING BALLS



#### DISTRIBUTION

Eversys operates through a network of fully trained and reliable national and regional distributors. These partners provide a fully integrated service provision ranging from machine sales and servicing through to user training.

c'2 Cameo™, e'Connect™, e'Barista™, e'Foam™ and e'Clean™ are trademarked property of Eversys AG. This manual is designed for final user purpose only and information can be changed at any time without amending these instructions.



**Thank you for purchase!** The technical specifications, illustrations and dimensions contained in these instructions are given only as a guide. They may not be the subject of any claim. The manufacturer reserves the right to make technical improvements to its equipment, without amending these instructions. For all additional information, please contact your Eversys AG representative.